


Válvula de Ar - AJV

VÁLVULAS DE AR

Valores de referência


CÓDIGO	D	L
CVJ06	6	12
CVJ08	8	15
CVJ10	10	20
CVJ12	12	25
CVJ16	16	30
CVJ18	18	30
CVJ20	20	30
CVJ25	25	30
CVJ30	30	30



Válvula de Ar - APV

Valores de referência

CÓDIGO	A	B	C	D	E
CVP08	8	6,6	11	24	6
CVP10	10	8	11	24	6
CVP12	12	9,7	18	34	8
CVP16	16	13	20	38	8
CVP18	18	14,8	22	45,5	12
CVP20	20	16	26	50	12
CVP25	25	20	26	50	12



Válvula de Ar - VA

Valores de referência

CÓDIGO	A	B	C
CVA05	5	3	12
CVA06	6	5,2	12
CVA08	8	6,5	12
CVA10	10	8	12
CVA12	12	10	12
CVA16	16	13	20
CVA20	20	17	20

